

LIQUID LEVEL INDICATOR (LLi)

DESCRIPTION

The Liquid Level Indicator (LLi) provides a means of verifying the weight of agent in a container without having to remove the container and weigh it on a calibrated scale.

This device enables the inspector to determine the weight of agent with the container safely secured in its installed position.


LLi's are furnished on the 100, 150, 215, 375, 650 and 1000 lb. (44, 61, 88, 153, 267 and 423 L) containers. Refer to the following Liquid Level Indicator Manuals for additional information concerning its installation and use:

- P/N 06-548 LLi Manual for ECARO-25® containers
- P/N 06-549 LLi Manual for FM-200 containers

Warning: The Liquid Level Indicator (LLi) **MUST** be installed while the Container is **EMPTY**.

APPROVALS:

- UL Listed
- ULC Listed
- FM Approved



Container Size lb. (L)	LLi P/N
100 (44)	70-1353-27
150 (61)	70-1353-14
215 (88)	70-1353-18
375 (153)	70-1353-27
650 (267)	70-1353-38
1000 (423)	70-1353-49

(This page is left blank intentionally)